



THANK YOU FOR PURCHASING A UNIDEN PRODUCT
CHECK OUT THE LATEST ACCESSORIES
www.uniden.com


GMR855-2/GMR855-2CK

- Power Boost Button for Maximum Range
- 15 GMRS / 7 FRS Channels
- Up to 8 Mile Range*
- 5 Selectable Call Tone Alerts
- Backlit LCD Display
- Battery Recharge Circuit
- Roger Beep
- Key Beep on/off
- Battery Level Meter
- Channel Monitor
- Channel Scan
- Keypad Lock
- Belt Clip
- NiMH Battery Pack and Charger (GMR855-2CK only)



* Range may vary depending on environmental and/or topographical conditions.

GMR855-2/GMR855-2CK RADIO



- | | |
|-----------------------------|-----------------------------|
| 1 Antenna | 13 Battery Level Meter |
| 2 PTT (Push-To-Talk) Button | 14 Receive Indicator |
| 3 Power boost Button | 15 Scan Indicator |
| 4 Monitor Key | 16 Channel Indicator |
| 5 Channel/Scan Up Key | 17 Power Boost Indicator |
| 6 Channel/Scan Down Key | 18 Volume Setting Indicator |
| 7 Speaker | 19 GMRS/FRS Indicator |
| 8 Call Key | 20 Transmit Indicator |
| 9 Volume Up Key | 21 Call Indicator |
| 10 On/off/select Key | 22 Keypad Lock Indicator |
| 11 Volume Down Key | 23 Charging LED's |
| 12 Microphone | |

Congratulations on your purchase of the Uniden GMR855-2/GMR855-2CK (General Mobile Radio Service) radios. These products are lightweight, palm-sized radios. Use them at sporting events to stay in contact with family and friends, hiking, skiing, outdoors, or in a neighborhood watch for vital communication. These compact, state-of-the-art devices are equipped with many features.

PACKAGE CONTENTS

- Your package contains 2 radios, 2 reference guides including the product registration card, and 2 Belt Clips. The GMR855-2CK also contains NiMH Battery Packs, Dual Drop-in Recharging Cradle and AC adapter. The following optional accessories may be purchased from your participating Uniden dealer or call 1-800-554-3988 or visit us on the web at www.uniden.com. Use only Uniden accessories.
- NiMH Battery Pack - #BP38
 - Recharging Cradle - #RC6348
 - AC Adapter - #AC6248

FCC GMRS LICENSE

The GMR855-2/GMR855-2CK radio operates on the General Mobile Radio Service (GMRS) frequencies which require a Federal Communication Commission license to operate. For licensing information and application forms, visit the FCC online at: www.fcc.gov/wtb/uls or call the FCC hotline at 1-800-418-3676. If you have any questions you can contact the FCC direct at 1-888-225-5322.

INSTALL THE BATTERIES

Your GMR855-2/GMR855-2CK radio uses 4 AAA alkaline batteries or NiMH battery pack (included in GMR855-2CK only). If alkaline batteries are used, we recommend using high quality alkaline batteries.

- To install the 4 AAA alkaline batteries or Ni-MH battery:
- 1) Make sure your radio is OFF.
 - 2) Remove the battery compartment door by pressing up the tab at the bottom of the compartment door allowing the door to be removed.
 - 3) Install 4 AAA alkaline batteries (not included) into the battery compartment. Be certain to follow the + and - symbols in the compartment. If you use Ni-MH battery, install the battery making the label faced up. Installing the batteries incorrectly will prevent the unit from operating.
 - 4) Replace the battery compartment door.

BATTERY LEVEL AND LOW BATTERY ALERT

This unit has a battery level meter on the display to indicate the status of the batteries. When the batteries in the unit are very low, the battery level meter icon will flash. Replace the alkaline batteries immediately or if you are using the NiMH battery pack, you must recharge the battery in order to continue using the radio.

Warning! To avoid the risk of personal injury or property damage from fire or electrical shock, only use the Uniden accessories specifically designated for this product.

USING THE CHARGING CRADLE

If you use the rechargeable NiMH battery pack, two GMR855-2CK radios can be charged by using the charging cradle.

Make sure to turn the radio OFF before placing the radio in the charging cradle. Otherwise the battery level meter icon won't indicate properly.

- 1) Connect the AC adapter (# AC6248) to DC IN 9V jack and to a standard 120V AC wall outlet.
- 2) Set the charging cradle on the desk or tabletop, and place the radio in the charging cradle with the keypad facing forward.
- 3) Make sure that the LED illuminates. Charge the battery pack for 16 hours and remove the radio from the charging cradle after charge.

Note: The charge indicator LED's will remain on as long as the radios are left in the charger.

USING THE RADIO

In order to get the most out of your new radio, read this reference guide completely before attempting to operate the unit.

Turning the Radio On and Adjusting the Volume


- 1) Press and hold the **sel/** key to turn the unit ON, and increase the speaker volume by pressing the volume **▲** key. To decrease the volume, press the volume **▼** key.
- 2) Press and hold the **sel/** key again to turn the unit OFF.

Adjusting the Sound (Key Beeps)

Your radio emits a beep each time one of the buttons or keys (except for the **PTT** and **Power boost** button, and **call** key) are pressed. To turn this sound OFF, press and hold **call** key while turning ON the radio. Repeat this step to turn the sound ON.

Navigating through the Menu

To access the advanced features of the GMR855-2/GMR855-2CK, your radio has a Menu function.



- 1) To enter the Menu, press the **sel/** key.
- 2) Additional presses of the **sel/** key will advance you through the Menu until exiting to "Normal" operating mode.
- 3) Other methods of exiting the Menu function are:
 - a. Press and hold the **sel/** key again.
 - b. Press the **PTT** or **Power boost** button, or **mon**, **volume ▲/▼**, and **call** key.
 - c. Wait 10 seconds until the unit automatically returns to "Normal" mode.

Choosing a Channel

Your radio has 22 channels you can use to talk to others. In order to speak to someone, each of you must be set to the same channel.

To choose a channel:

With the radio in "Normal" operating mode press the **ch/scan ▲** or **▼** key to increase or decrease the channel number displayed.

Note: FRS Channels 8-14 have an expectancy range of up to 3 miles. GMRS channels 1-7, 15-22 have an expectancy range of up to 8 miles by pressing the **Power boost** button.

Talking on Your Radio

To talk to others using the radio:

- 1) Press and hold the **PTT** button and speak in a clear, normal voice about 2-3 inches away from the microphone. While you are transmitting, the **tx** icon will appear on the display. To avoid cutting off the first part of your transmission, pause slightly after pressing the **PTT** button before you start talking.
- 2) When you are finished speaking, release the **PTT** button. You can now receive incoming calls. While receiving, the **rx** icon will appear on the display.

Note: When you press the **Power boost** button, **boost** and **tx** icon appear on the display. The radio will transmit Maximum power when a GMRS channel is selected. After one minute past when the boost transmission is established, the transmission stops automatically, and you will hear a boost time out error tone.

Transmitting a Call Tone

Your GMR855-2/GMR855-2CK radio is equipped with 5 selectable call tones that will be transmitted when the **call** key is pressed.

To select a call tone:

- 1) Enter the Menu. Advance through the Menu until the **call** icon is shown on the display. The current call tone number (**1-5**) will be indicated.
- 2) Press the **ch/scan ▲** or **▼** key to increase or decrease the number to the desired call tone. Each tone will be heard through the speaker.
- 3) Exit the Menu.

To transmit the selected call tone, press the **call** key. The selected tone will automatically be transmitted for a fixed length of time.

Keypad Lock

To Lock the keypad:

- 1) Enter the Menu. Advance through the Menu until the **lock** icon appears on the display. The current key Lock status (**OFF**) blinks on the display.
- 2) To switch the key Lock mode from **OFF** to **ON**, press the **ch/scan ▲** key.
- 3) To confirm the setting, press the **sel/** key. The radio returns to the "Normal" mode.

Note: If you exit the setting mode before confirming your selection by pressing the **sel/** key, the key Lock setting will be set to **OFF**.

To Unlock the keypad:

- 1) Press and hold the **sel/** key to turn the unit OFF.
- 2) Press and hold the **sel/** key again to turn the unit ON. The keypad is unlocked.

Channel Scan Feature

Your GMR855-2/GMR855-2CK radio has a channel Scan feature that allows you to easily Scan all 22 channels. When an active channel is detected, the unit will pause on that channel until the channel is clear. Then after a 2 second delay, the unit will continue scanning. Pressing the **PTT** or **Power boost** button while the Scan is paused on a channel will allow you to transmit on that channel.

To turn ON channel scanning:

Press and hold either the **ch/scan ▲** or **▼** key until the **scan** icon is displayed. The channel number on the display will change as the radio rapidly cycles through the channels.

To turn OFF channel scanning:

Press the **sel/** key, **call** key, **Power boost** button or **PTT** button.

Automatic Power Save Feature

Your GMR855-2/GMR855-2CK radio has a unique circuit designed to dramatically extend the life of the batteries. If there is no transmission nor an incoming call within 3 seconds, your radio switches to the Power Save mode. The radio is still able to receive transmissions in this mode.

LCD Backlight

The LCD backlight will automatically turn ON when any key (except for the **PTT** and **Power boost** button) is pressed. The LCD display will illuminate for 10 seconds before turning OFF.

Monitor Mode Feature

Your GMR855-2/GMR855-2CK radio allows you to listen for weak signals on the current channel at the press of a key.

To turn ON the monitor mode:

- Press **mon** for brief listening, the **rx** icon will blink.
- Press and hold **mon** for 2 seconds for continuous listening. The receiver circuit will stay open, and letting in both the noise & weak signals.

To turn OFF monitor mode:

- Press **mon** to return to "Normal" mode, and the **rx** icon stops blinking.

Roger Beep

Roger Beep is a BEEP that is sent to notify the end of transmission (PTT transmission.) Roger Beep can be heard through the speaker when Key Beep is on. If key beep is turned off, Roger Beep will not be heard from the speaker.

To turn ON Roger Beep:

Press and hold the **ch/scan ▲** key while turning ON the radio.

To turn OFF Roger Beep:

Press and hold the **ch/scan ▲** key while turning ON the radio.

Please do not send products or other correspondence to this address.

039 Q



Uniden®
PRODUCT REGISTRATION DEPARTMENT
PO BOX 44486
DENVER CO 80201-4486
USA



Uniden®
PRODUCT REGISTRATION CARD

Failure to complete and return this card does not diminish the consumers warranty rights concerning this product.

PLEASE FOLD AND SEAL WITH TAPE BEFORE MAILING. DO NOT STAPLE.

PLACE
 FIRST-CLASS
 STAMP
 HERE

Please fill-out and return this card within 10 days!



1 First name: Initial: Last name: Address: Apt number: City: State: Zip code:

2 E-mail address: 1. Yes! I want to receive offers or communications from Uniden via e-mail. 2. Yes! I want to receive offers or communications that may interest me from other companies via e-mail.

3 Date of purchase: Month Day Year

4 Purchase Price: \$.00 (excluding tax)

5 Serial Number: (Located on the back of each unit)

6 Model Number: (Example: GMR540-2, WX500)

7 Which Uniden product did you purchase? 1. FRS/GMRS Radio 2. Weather Radio

8 Store Name:

9 Check the two (2) most important reasons influencing your purchase of this Uniden Product: 1. Uniden reputation 2. Previous experience 3. Features 4. Value for price 5. Quality/durability 6. Style/appearance 7. Warranty 8. Received as a gift 9. Other

10 Check the two (2) most important features to you on this Uniden product: 1. Range 2. Low battery alert 3. Clarity 4. Number of channels 5. Auto squelch 6. Color 7. Design 8. Channel scan 9. LCD backlight

11 How did you first become aware of this product? 1. Previous Use 2. Comparison Shopping 3. In-Store Display 4. Newspaper Ad 5. Magazine Ad 6. TV Ad 7. Recommendation of Salesperson 8. Recommendation of Friend/Family 9. Direct Mail

12 Your gender: 1. Male 2. Female

13 Your marital status: 1. Married 2. Single

14 Date of your birth: Month Day Year

15 Including yourself, how many people live in your household? (Examples: 01, 02, etc.) Children (18 and younger) Adults

16 Date of birth of children in your household 18 years of age and younger: Gender Male Female Birth Date Month Year Child #1 Child #2

17 For your primary residence, do you: 1. Own 2. Rent

18 Education: (Please check which category applies to you): 1. Some high school 2. Completed high school 3. College degree 4. Graduate degree

19 I/we buy these things through the mail, over the Internet, or from television: 1. Books/magazines 2. Checks (not from a bank) 3. Children's products 4. Clothing 5. Computer products 6. Cosmetics/jewelry 7. Crafts/hobbies 8. Gardening supplies 9. Gifts 10. Housewares/furnishings 11. Insurance/financial products 12. Music/video/DVD 13. Sports equipment 14. Travel 15. Other A. Mail B. Internet C. TV

20 I/we have these credit cards: 1. American Express/Diners Club 2. Discover 3. Retail/Gas 4. Visa/MasterCard 5. Other 6. None

21 Someone in my home enjoys: 1. Astrology 2. Auto racing 3. Automotive work 4. Books 5. Camping/hiking 6. Casino gambling 7. Cigars 8. Collecting 9. Computers/Internet 10. Cooking/recipes 11. Crafts/needlework 12. Cultural art/events 13. Cycling 14. Dieting/weight control 15. Do-it-yourself 16. Donating to charity 17. Fishing 18. Fitness/exercise 19. Gardening 20. Golf 21. Gourmet food/cooking 22. Grandchildren 23. Home decorating 24. Hunting/shooting 25. Investing 26. Lottery/sweepstakes 27. Pets-cats 28. Pets-dogs 29. Pets-other 30. Photography 31. Play sports 32. Self improvement 33. Skiing/snowboarding 34. Travel-Foreign 35. Travel-U.S. 36. Vacation cruises 37. Vitamins/natural foods 38. Wines 39. Woodworking 40. Worship/Bible

SPECIFICATIONS

Channels 15 GMRS / 7 FRS Operating Frequency UHF 462.5500-467.7125 MHz Power Source 4 AAA Alkaline Batteries or NiMH Battery Pack Range Channels 8-14 up to 3 miles Channels 1-7, 15-22 up to 6 miles Battery Life 25 Hours typ. - Alkaline Batteries (5/5/90 duty cycle) 15 Hours typ. - NiMH Battery Pack

FCC INFORMATION

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired operation. Important: Changes or modifications to this unit not expressly approved by Uniden could void your authority to operate this unit. Your radio is set up to transmit a regulated signal on an assigned frequency. It is against the law to alter or adjust the settings inside the radio to exceed those limitations. Any adjustments to your radio must be made by qualified technicians. To be safe and sure: Never open your radio's case. Never change or replace anything in your radio except the batteries.

Frequency Chart

Table with 4 columns: Ch. No., Freq. (MHz), Cross Reference, TX Power (ptt/vox), TX Power (Boost). Rows 1-22.

FCC RF EXPOSURE INFORMATION

WARNING! Read this information before using the radio. In August 1996 the Federal Communications Commission (FCC) of the United States with its action in Report and Order FCC 96-326 adopted an updated safety standard for human exposure to radio frequency electromagnetic energy emitted by FCC regulated transmitters. Those guidelines are consistent with the safety standard previously set by both U.S. and international standards bodies. The design of the radio complies with the FCC guidelines and these international standards. Never allow children to operate the radio without adult supervision and the knowledge of the following guidelines. WARNING! It is up to the user to properly operate this radio transmitter to insure safe operation. Please adhere to the following: Use only the supplied or an approved antenna. Unauthorized antennas, modifications, or attachments could impair call quality, damage the radio, or result in violation of FCC regulations. Do not use the radio with a damaged antenna. If a damaged antenna comes into contact with the skin, a minor burn may result. Please contact your local dealer for a replacement antenna. Body-worn Operation This device was tested for typical body-worn operations using the supplied belt-clip. To maintain compliance with FCC RF exposure requirements, Body-worn operations are restricted to the supplied belt-clip. For hand-held operation, the radio should be held 1 inch from the user's face. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements and should be avoided. For more information about RF exposure, please visit the FCC web site at www.fcc.gov.

ONE YEAR LIMITED WARRANTY

Important: Evidence of original purchase is required for warranty service. WARRANTOR: UNIDEN AMERICA CORPORATION ("Uniden") ELEMENTS OF WARRANTY: Uniden warrants, for one year, to the original retail owner, this Uniden Product to be free from defects in materials and craftsmanship with only the limitations or exclusions set out below. WARRANTY DURATION: This warranty to the original user shall terminate and be of no further effect 12 months after the date of original retail sale. The warranty is invalid if the Product is: (A) damaged or not maintained as reasonable or necessary, (B) modified, altered, or used as part of any conversion kits, sub-assemblies, or any configurations not sold by Uniden, (C) improperly installed, (D) serviced or repaired by someone other than an authorized Uniden service center for a defect or malfunction covered by this warranty, (E) used in any conjunction with equipment or parts or as part of any system not manufactured by Uniden, or (F) installed or programmed by anyone other than as detailed by the owner's manual for this product. STATEMENT OF REMEDY: In the event that the product does not conform to this warranty at any time while this warranty is in effect, warrantor will either, at its option, repair or replace the defective unit and return it to you without charge for parts, service, or any other cost (except shipping and handling) incurred by warrantor or its representatives in connection with the performance of this warranty. Warrantor, at its option, may replace the unit with a new or refurbished unit. THE LIMITED WARRANTY SET FORTH ABOVE IS THE SOLE AND ENTIRE WARRANTY PERTAINING TO THE PRODUCT AND IS IN LIEU OF AND EXCLUDES ALL OTHER WARRANTIES OF ANY NATURE WHATSOEVER, WHETHER EXPRESS, IMPLIED OR ARISING BY OPERATION OF LAW, INCLUDING, BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. THIS WARRANTY DOES NOT COVER OR PROVIDE FOR THE REIMBURSEMENT OVERPAYMENT OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. Some states do not allow this exclusion or limitation of incidental or consequential damages so the above limitation or exclusion may not apply to you. LEGAL REMEDIES: This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. This warranty

is void outside the United States of America and Canada. PROCEDURE FOR OBTAINING PERFORMANCE OF WARRANTY: If, after following the instructions in the owner's manual you are certain that the Product is defective, pack the Product carefully (preferably in its original packaging). The Product should include all parts and accessories originally packaged with the Product. Include evidence of original purchase and a note describing the defect that has caused you to return it. The Product should be shipped freight prepaid, by traceable means, to warrantor:

Uniden America Corporation Parts and Service Division 4700 Amon Carter Blvd., Fort Worth, TX 76155 (800) 297-1023, 8 a.m. to 5 p.m. Central, Monday through Friday www.uniden.com

Covered under one or more of the following U.S. patents: 4,684,870 4,734,049 5,203,015 5,214,789 5,491,745 5,497,508 5,517,677 5,557,606 5,574,994 5,610,946 5,613,201 5,625,870 5,627,876 5,628,059 5,634,196 5,634,205 5,678,176 5,697,096 5,717,312 5,722,070 5,787,345 5,901,341 6,021,326 6,084,861 6,163,691 6,195,415 6,353,730



© 2004 Uniden America Corporation All rights reserved Printed in China UTZZ01917ZB

Thank you for completing this questionnaire. Your answers will help us and other companies reach you with offers that may interest you. If you prefer not to receive these offers, please check here [].

PLEASE FOLD AND SEAL WITH TAPE BEFORE MAILING. DO NOT STAPLE.