



WB-1: (AC/DC-6) 17 (L) x 7 3/16 (H) x 4 1/4 (D) inches  
WB-2: (AC/DC-3) 8 1/2 (L) x 7 3/16 (H) x 4 1/4 (D) inches

## Recommended Installation:

- The bracket should be positioned so the four lag bolts will screw into a wall stud.
- Pre-drilling the holes is recommended.
- The bracket should then be attached using the four 1/4 inch by 2 inch long lag bolts and washers supplied with the bracket.
- When attaching into wallboard, use the screw anchors provided by drilling four 5/16 inch pilot holes.

## Installation & Removal of Charging Station:

- Place the charging station on the bracket and pull away from the wall while pushing down lightly. The tabs on the bracket will engage the slot in the charging station and hold it.
- Wedge the securing strip between the charging station and vertical flange of the bracket. The strip will keep the charging station from being accidentally removed.
- To remove the charging station, simply pull out the strip and push the charging station forward while lifting up.



1635 Abbott St, Suite 105 Kelowna, British Columbia  
Canada V1Y 1A9  
Toll Free: 1-866-532-9005  
Tel: 250-868-3444 ext 103  
Fax: 250-868-3404

REV -  
4-26-07