


KENWOOD

Installation:

- (1) Turn the radio off before plugging in the Earpiece.

Note: Installation of the Earpiece while the radio is on may cause unwanted transmit or may cause your radio to jump to another channel. If this should happen, turn off the radio. The radio can then be turned back on, restoring normal operations.

- (2) Attach Earpiece to the radio accessory connector.
- (3) The Earpiece can be worn on either ear, with or without the removable C-Ring.
- (4) C-Ring Earpiece can be re-shaped to fit your ear size. Simply reduce or enlarge the C-Ring shape for a comfortable fit.



Operation:

Turn ON and operate the radio as explained in the radio operating instructions. Installing the Earpiece (1) bypasses the radio's speaker and routes the sound to the Earpiece, and (2) disables the radio's microphone and enables the Earpiece microphone.

Microphone position is recommended on or close to the collar (shortest distance to the mouth).

Microphone is activated by either radio push to talk or the in-line push to talk. When using VOX (voice operated transmit) equipped radios, refer to the radio instruction manual for VOX operating instructions.

Turn it down: Use the minimum receiver volume necessary. Kenwood wants you listening for a lifetime.

Kenwood USA Corporation, Communications Sector
P.O. Box 22745 (mail)
2201 E. Dominguez St.
Long Beach, CA 90801-5745
Phone: 800-725-0986 Fax: 310-761-8246

Kenwood Electronics Canada, Inc.
6070 Kestrel Road Mississauga, Ontario L5T1S8
Phone: 905-670-7211 Fax 905-670-7225



CB

Recycle this #4 Plastic Package!

MADE IN CHINA



0019048199072