

Bluetooth Hand Microphone Users Manual

Thanks for purchasing Bluetooth Hand Microphone.
Please read the "Safety Instructions" before using.


Caution

- ◆ Do not immerse in water to avoid damaging the product as well as shortening its lifetime
- ◆ DO NOT drop or apply shock to the product. Such act may cause irreparable damage to the Product..
- ◆ DO NOT expose the product to open flame or under the direct sunlight for a prolonged period of time. Such environment may cause malfunction or fire.
- ◆ Please do not operate our product while driving. It may cause an accident.
- ◆ Talking on the cell phone when driving is extremely dangerous. Avoid talking on a ride. Get into the habit of talking after parking safely by the side of the road.
- ◆ If smoke, ironing, odour and other anomalies occur, please cut off the power supply immediately and stop using. If you continue to use it, it will cause electric shock, fire and other accidents.
- ◆ Do not disassemble or modify this product, otherwise it will cause product damage or electric shock, fire and other accidents.
- ◆ Do not put this product in the population to avoid the occurrence of injury accidents. Users with children at home need special attention. Store it carefully. Stay away from children.
- ◆ Temperature range of use: -15° C-45° C
- ◆ In order to guarantee the normal function of our product, please use only qualified accessories which have been authenticated by us.

Note on battery charge

- ◆ Please use the USB cable attached to charge, otherwise it will cause smoke, fire and so
- ◆ For battery charge, use USB terminal or USB adaptor at normal temperature.
- ◆ Use regulation USB terminal only. Otherwise it may cause smoke generation or fire.
- ◆ When charging the battery, if any strange odor or high heat occur, please immediately pull the plug from the product, It may cause smoke generation or fire.
- ◆ Do not leave the product in the state of charge for a long time after the charging is completed. It may cause smoking or ignition.
- ◆ Charge battery at least once every six months even if the product is used for a long time.

Product Description



- 1.PTT: push this button to talk. (Wireless PTT controllers are the same.)
- 2.PTT: programmable button.
- 3.MIC
- 4.Indicators
- 5.P1: for answering or hanging up phone calls. In media mode, press 1 second to pause or play music.
- 6.Volume +: press volume + button to turn up the volume, when maximum volume reached, a remind tone will be played. In media mode, long press "+" for 2 seconds to next song.
- 7.Volume -: press volume - button to turn down the volume. In media mode, long press "-" for 2 seconds to previous song.
- 8.Power on / off : press 3 seconds to turn on/off; press 6 seconds to pairing mode in power off state.
- 9.Speaker
- 10.Earphone jack: for external earphone
- 11.Charging port: DC 5V

Bluetooth Hand Microphone

- ◆ Dual-purpose PTT function for phone and two way radios

Before using the hand microphone, please charge the it.

- ◆ Make sure your hand microphone is fully charged before use
- When the indicator light is red, it indicates that the headset is charging. When the hand microphone is fully charged, the indicator light will be off. Please note that if the hand microphone is not used for a long time, the battery life will be greatly shortened. Please charge it at least once a month.

Operation

- ◆ power on
In the state of power off, press the power key for 3 seconds , the blue light will flash slowly.
- ◆ power off
When it is on, press the power key for 6 seconds. All indicator lights are turned off.

Pairing with mobile phone

- ◆ Make sure the Bluetooth hand microphone t is power off.
- ◆ Press the power key for about 6 seconds, when the blue light and the red light flash alternately, release the button , the Bluetooth hand microphone will be in pairing state.
- ◆ Follow the user manual of your mobile phone, turn on the Bluetooth function and search the Bluetooth hand microphone named "HB980D" , then pair with it. The phone will confirm when the matching is completed, and the blue light will flash slowly.

Note:

1. Password code may be not necessary for some mobile phones.
2. Bluetooth hand microphone and mobile phones need to be matched only for the first time. When the headset is matched with the phone , they will pair with each other next time.

PTT (Push To Talk) Function

After connected the headset to two way radios or car radios , you can use helmet hand microphone to control the two way radios by pressing PTT button .

Answer incoming call

- ◆ Press P1 / wireless P1 button to answer the call. Press again to end the call.

Volume control

- ◆ Press volume + button to turn up the volume, when maximum volume reached, a remind tone will be played. In media mode long press "+" for 2 seconds to next song. Press volume - button to turn down the volume. In media mode, long press "-" for 2 seconds to previous song.

Noise reduction

- ◆ Press Power and Volume - button simultaneously. You will hear voice prompt.

Language switching

- ◆ Press Power and Volume + button simultaneously. You will hear voice prompt.

Pairing elimination

- ◆ Press Volume + and Volume - button simultaneously. You will hear beep.

Technical Specification:

Bluetooth version	V4.1 Class2
Operation range	10m
Profile	HFP,HSP,PTT
Stand by time	About 600 hours
Charging time	Less than 3 hours
Working temperature	-15° C-45° C
Storage temperature	-25° C-60° C

About LED Indicator and Charging

LED indicator flash mode	State of Indication
Blue light flashes every second	Working/Standby mode
Red and blue light flash fast alternately	Pairing mode
Red light flashes slowly	Low Battery
Red light is on	Charging
PTT red light is on	PTT button is pressed
P1 red light is on	PTT button is pressed
All indicators are off	Charging completed

FAQ :

Crackle Sound

- ◆ Put hand microphone closer(less than 10 meter range)to your cell phone or two way radio in a non-obstacle area.

No sound

- ◆ Please check if the speaker mic have connected to the device or the volume is too low.

Disconnect with mobile phone, Adapter/dongle

- ◆ Make sure if it is low battery. If not, make sure the distance between the speaker mic and mobile phone is within 10m or whether there exists obstacles between them.

Fail to re-connect or automatically re-connect with mobile phone

- ◆ First make sure your Bluetooth function in your mobile phone have been turned on, then remove all the paired Bluetooth device in you cell phone. Then turn off your mobile phone, restart mobile phone and pair with Bluetooth speaker-mic and set the headset as "default/trust/test/permit/automatically connection/always visible/allow to be found" device,then further ensure that the phone prompt tone is not vibrating mode (because the vibrating impulse wave would disturb Bluetooth frequency signal sometimes), it will repair and connect with your mobile phone. For android system, please make sure in the Bluetooth device option list, you have "Phone" options selected.

无线蓝牙手麦说明书

感谢您购买无线蓝牙手麦
希望您能喜欢本说明书帮助您充分了解和您的蓝牙手麦

安全注意事项


- ◆禁止跌落以及冲击等有害本产品的行为发生，否则会造成机器故障的发生。
- ◆请勿长时间将本产品放在近火或阳光直射的地方。否则会引起火灾等故障的发生。
- ◆禁止在骑乘摩托车的同时，进行本产品的设定变更、手机通话等操作，以免引起交通事故的发生。万一，因骑乘过程中操作本产品或不当使用本产品而产生的任何伤害，本公司概不负责，敬请谅解。
- ◆避免骑乘中的通话行为。养成在路边安全停车之后再行进行通话的习惯。
- ◆发生口烟、发热、异味等异常时，请立即切断电源，并停止使用。如果继续使用可能会引起触电、火灾等事故的发生。
- ◆请勿拆卸、改装本产品，否则会造成产品破损或者触电、火灾等事故发生。
- ◆请勿将本产品放入口中，避免伤害事故的发生。家有儿童的使用者需要特别的注意存放。远离儿童。
- ◆本产品可在15C-45C的温度环境中使用，超过此温度范围，本公司无法保证产品可以正常使用。
- ◆本公司产品所附配件均经过认证检验，如使用非本公司认证的配件可能影响产品正常使用。

安全注意事项

- ◆请务必使用本公司附带的USB线充电，否则会引起口烟、起火等情况的发生。
- ◆如长时间不使用本产品时，至少半年充电一次，以免过度放电而导致电池损坏。
- ◆充电请使用PC的USB端子或者附带的USB端子输出电源适配器，并在常温下进行。请避免在近火处进行充电，以免引起口烟和起火等情况的发生。

- ◆充电完成后，请不要使其长时间处于充电状态，以免引起口烟和起火等情况的发生。
- ◆充电过程中，如果发生异味、发热等异常情况，请立即切断电源，停止充电，以免引起口烟和起火等情况的发生。

熟悉本机



- 1、按键PTT发射键(1)配合(蓝牙适配器)使用
- 2、按键PTT发射键(2)可根据需求定义
- 3、MIC送话器
- 4、指示灯
- 5、P1按键：P1电话接听/挂机功能。当来电话时按下此键接听电话/电话挂机。在待机模式下短按控制音乐播放/暂停。(需软件适配)
- 6、音量+键：在喇叭工作时按一下音量+；长按此键为播放上一首。
- 7、音量-键：在喇叭工作时按一下音量-；长按此键为播放下一首。
- 8、电源开关：长按开机/关机；关机状态下长按6秒进入配对状态(红蓝灯闪烁)。
- 9、扬声器
- 10、扩展耳机线插口
- 11、充电接口：DC 5V 输入

手麦功能

- ◆PTT功能专用平台对讲机(PTT)1按键(PTT)2按键可定

注：在使用手麦之前，请为手麦充电

- ◆为了更好地使用蓝牙手麦，请确保您的耳机在使用前先充电两个小时然后再行使用。当指示灯呈红色时，表示手麦正在充电。当手麦完全充满电时，指示灯将变为灭。请注意：如果长时间不对手麦充电，电池寿命会大大缩短。因此建议您每月至少为耳机充一次电。

开机和关机

- ◆关机状态下，往电源图标(⏻)长按开关配对键3秒，蓝灯恒闪为开机。
- ◆开机状态下，往电源图标(⏻)长按开关配对键2秒所有指示灯关闭为关机。

手麦与手机配对

- 1.使手麦处于配对模式
 - ◆首次开启手麦时，请在开关机的状态下，按电源图标(⏻)开关键6秒进入红蓝指示灯快闪，进入配对模式，打开手机蓝牙设置，搜索设备名：HB980D设备名，点击手机搜索到相关设备名，点击配对，配对成功后手机会显示连接成功，蓝牙耳机红蓝快闪指示灯进入蓝灯恒闪，即为配对成功。
- 2.设置蓝牙耳机，使之发现“HB980D”
 - ◆按照手机的说明书指南进行操作。首先确保已激活手机的蓝牙功能，然后设置手机使其找到手麦。这通常包括进入手机的“设置”、“连接”或“蓝牙”菜单并选择用来“发现”或“添加”蓝牙设备的选项。

通话功能

- ◆蓝牙手麦通话时对讲机优先，当你在使用手机蓝牙功能时只要对讲机接收到信号或按PTT键发射时，会自动切换到对讲机通话模式，对讲机通话完毕自动返回手机蓝牙模式。

注：如果你已经配好手机在使用了，这时候再配对对讲机适配器，配对完耳机需要重新开机，就会自动同时连接手机和对讲机适配器。

注意：

- 1.有些手机是不需要输入配对密码的。
- 2.手麦与手机仅在首次配合使用时需要配对。当手麦与手机完成首次配对之后，只要手麦开启且手机已激活蓝牙功能，它们就会自动连接。如果手麦与手机已配对但没有立即连接，请进入手机的蓝牙设置界面，选中配对的HB980D设备名，点击链接即可。

操作

- ◆同时配对对讲机或者车台适配器一起使用，也可以控制对讲机的PTT功能。

接听来电

- ◆轻按一下手麦上的按钮(P1)，接听来电，结束通话的按钮(p1)。

调节声音和音量

- ◆按一下“+”号音量按键，音量会增大一格。到达最高音量时，会听到音量最大语音提示。在多媒体状态下，长按“+”号音量按键，切换到下一曲。
- ◆按一下“-”号音量按键，音量会减小一格。在多媒体状态下，长按“-”号音量按键，切换到上一曲。

其他功能

- 降噪：同时按下开关机键(⏻)和音量-键
- 中英文提示音切换：同时按下开关机键(⏻)和音量+键
- 清除所有配对：同时按下音量+键和音量-键，听到“嘟嘟”两声提示音表示清除成功。

技术参数

版本	蓝牙V4.1
射频等级	Class 2
传输范围	10米
支持模式	HFP,HSP,PTT
待机时间	600小时
充电时间	小于3小时
工作温度	-15°C-45°C
存储温度	-25°C-60°C

LED状态及充电指示

LED指示灯闪烁模式	状态指示
蓝灯每1秒闪烁一次	工作/待机模式
红蓝灯交替快闪	配对模式
红灯每2秒闪烁一次	低电量
红灯长亮	正在充电
设备灯全部灭	充电完成

故障排除和常见问题解答：

- 我听到了嘟嘟的响声
 - ◆作为一种无线电技术，蓝牙对耳机与所连接设备之间的物体很敏感。根据设计规格，手麦与所连接设备的使用间距应保持在10米(33英尺)之内，而且二者之间不应存在大型物体(如墙壁等)。
- 我的手麦听不到任何声音
 - ◆增大手麦的音量。
 - ◆确保手麦已与正在通话的设备配对正确。
- 通过轻按“接听/结束”按钮确认手麦已与您的手机正确配对。配对不成功，怎么办？
 - ◆您可能在手机中删除了耳手麦配对连接。请按照配对说明操作。
- 无法开机，怎么办？
 - ◆把手麦插上USB充电线充电3小时直至红灯长亮再次重新开机。