

## Installation:

- (1) Turn the radio off.
- (2) As required, remove any dust caps or covers from the radio accessory connector.
- (3) Attach headset to the radio accessory connector.
- (4) If applicable, install appropriate accessory clamp.



## PTT Options:

Model	Features	Compatible Radios
KHS-7	Lightweight Headset	TK-250/350 TK-260/360 TK-270/370
KHS-7A	Lightweight Headset with PTT	TK-250/350 TK-260/360 TK-270/370
KHS-14	Lightweight Headset with PTT	TK-290/390 TK-400/481

## Operation:

Turn the radio on and operate it as explained in the operating instructions supplied with the radio. Installing the headset (1) bypasses the radio's speaker and routes the output to the headset's speaker, and (2) disables the radio's microphone and enables the boom microphone.

Microphone position is adjusted by rotating and bending the boom arm (X) to place the microphone to within one inch of the mouth.

Replacement Parts	Part Number
Foam Microphone Windscreen (5)	C807027-05
Foam Earphone Cushions (2)	C807028-02

## NEW

Kenwood Lightweight Headsets now have a lower profile plug compatible with the accessory clamp supplied with the radio.

Replacement or optional parts may be ordered from:  
OTTO Communications, 2 E. Main St., Carpentersville, IL 60110,  
888-234-6886, or 847-428-7171, or Fax 847-428-1956.  
The product is covered by KENWOOD's one year warranty. For  
warranty information or customer support, please contact  
Kenwood at the address listed on the back page.

