

Hardwire Kit Installation Instructions

Part No. 206880

This accessory is designed for the use of all Whistler 1600, 1700, XTR & Pro series radar/laser detectors.

Power Cable Connection

The power cable has a plug on one end which connects to the detector. At the other end of the power cable, the power and ground wires are separated. The ground wire has a "U" type connector which should be fastened to a metal surface. Look for an existing screw or bolt under the dash to use as a grounding point. The power wire has a spade type connection which should be connected to a switched +12 volt DC circuit in your vehicle's fuse box. A switched circuit is one that has power when you vehicle is on, but has no power when your vehicle is off. Connect the "U" type connector to the ground point selected. Attach the power cord plug to the detector. Then touch the power wire to the +12 volt DC switched power source selected. If the detector sounds the self test sequence, then all connections are correct.